

This protocol is for use with the Qu-16, Qu-24, Qu-32, Qu-Pac and Qu-SB loaded with firmware version V1.9 or later.

Note Firmware V1.9 added new MIDI messages for:

- Remote shutdown command added.

Note For firmware V1.5 onwards the MIDI channel numbers and NRPN ID previously used by Mute Groups were re-allocated to the added DCA Groups to be consistent with other Allen & Heath mixers. Mute Groups channel numbers were changed and are as detailed in this specification.

Qu transmits MIDI messages when its controls are operated. It also responds to parameter changes it receives via MIDI, for example from a computer or an external MIDI controller.

MIDI communicates via:

USB – Rear panel USB B port for direct connection to Apple Mac computers running OSX 10.6 or later. This is the recommended connection for DAW control.

Note USB MIDI is supported natively by Apple Mac computers so no driver is needed. A driver for Windows computers can be downloaded from the [Allen & Heath web site](#).

TCP – Rear panel network port for use with a computer, a touch panel or other remote controller with configurable MIDI over a TCP/IP port.

Note TCP MIDI requires a driver for the data to be seen as a MIDI port. An Allen & Heath TCP MIDI driver for Apple Mac computers can be downloaded from the iLive Software web page. A driver is not available for Windows computers.

Note Qu currently allows only one TCP MIDI connection at a time over its Network port.

The following Qu functions can be controlled via MIDI:

- Mutes
- Faders and Pan
- Mix and FX sends - Level, Pan, Assign, Pre/Post
- Matrix sends (not Qu-16) – Level, Pan, Assign, Pre/Post
- Audio Groups (not Qu-16) – Assign, (plus Level, Pan, Pre/Post if in Mix mode)
- Mute Groups – Assign, Master Mute
- DCA Groups – Assign, Master Level, Master Mute
- PAFL select
- Input Channel source
- Preamp (local and dSNAKE) – Gain, Pad, 48V
- Insert In/Out
- Input Channel processing – Trim, Polarity, Gate, PEQ, Compressor, Delay
- Mix processing - PEQ, GEQ, Compressor, Delay
- Group and Matrix processing – PEQ, GEQ, Compressor, Delay (not Qu-16)
- Channel Names
- Scene Recall
- FX Tap Tempo
- MMC Transport Control
- Remote Shutdown

DAW Control for Mac computers:

MIDI fader strips can be assigned to the Custom Layer to work with a DAW (Digital Audio Workstation). These send/receive CC and note on/off messages using a different MIDI channel to that used for the Qu functions described above. The MIDI fader strip sends/receives messages relating to:

- Fader position
- Mute key / indicator
- Sel key / indicator
- PAFL key /indicator
- DAW Bank Up/Down

You can work directly with these messages or use the Allen & Heath DAW Control driver to convert them into either of the following popular protocols:

- HUI
- Mackie Control

Note DAW Control is available for Mac computers only. A driver for Windows computers is not available.

Go to the [Allen & Heath web site](#) to download the DAW Control driver for Mac and for further information in the DAW Control Setup Notes.

Reference

Refer to the table at the end of this document for value listings.

All MIDI message numbers shown in blue in this document are **Hexadecimal**

- Key**
- Blue** Hexadecimal number, eg, **F0**
 - Green** Variable referred to in table or note, eg, **VA** = parameter value
 - Red** NRPN **ID** number for parameter type, eg. Polarity = **6A**
 - Orange** NRPN Index to specify a second value, eg, **VX**

MIDI channel number **N** (see table)

MIDI channel 1 to 16 = **0** to **F**

Qu functions use MIDI channel = **N**

MIDI strips (DAW controls) use MIDI channel = **N+1**

Channel numbers **CH** (see table)

FX Send 1 to 4 = **00** to **03**

FX Return 1 to 4 = **08** to **0B**

DCA Groups 1 to 4 = **10** to **13** **Note** Introduced in V1.5 firmware

Input 1 to 32 = **20** to **3F**

Stereo Channels = **40** to **42**

Mute Groups 1 to 4 = **50** to **53** **Note** This is a change introduced in V1.5 firmware

Group 1-2 to 7-8 = **68** to **6B** (not Qu-16)

Mix 1 to 10 = **60** to **66**

Main LR = **67**

Matrix 1-2, 3-4 = **6C** , **6D** (not Qu-16)

Active Sensing

Qu supports MIDI Active Sensing over its TCP/IP Ethernet connection to detect connection status. Qu will send an initial Active Sense byte (**FE**) once an Ethernet connection is established, and then once every 300ms or so during any period of inactivity.

Qu also responds to Active Sense. If it receives an Active Sense byte it will expect to receive regular MIDI data from that point onwards (either valid control data, or more Active Sense bytes during any period of inactivity). If it does not receive any data for 12 seconds, it will close the Ethernet connection.

DAW control

MIDI strips assigned to the Custom Layer can provide DAW control.

DAW messages can be translated into HUI or Mackie Control protocol using the Allen & Heath **DAW Control** driver which can be downloaded from the [Allen & Heath web site](#).

Note DAW Control is available for Mac computers only. A driver for Windows computers is not available.

DAW messages use a different MIDI channel to other Qu MIDI messages:

Qu MIDI channel = **N**
DAW MIDI channel = **N+1**

MIDI strip controls send and respond to the following messages:

Strip Fader

Control Change message:

B(N+1), FD, VA

Where **FD** = Strip fader **00** to **1F** (see table)

VA = Fader min to max position = **00** to **7F**

Strip keys

The strip keys use **NOTE ON** followed by **NOTE OFF** messages.

Pressing keys send messages.

Key LED indicators respond to received messages.

9(N+1), KY, 7F, 9(N+1), KY, 00

Where **KY** = **Mute** Strip 1-32 = **00** to **1F** (see table)

Sel Strip 1-32 = **20** to **3F**

PAFL Strip 1-32 = **40** to **5F**

Bank Up/Down

Qu SoftKeys can be assigned as DAW Bank Up or Bank Down keys.

These use **NOTE ON** followed by **NOTE OFF** messages which are converted by DAW Control to become the Bank Up/Down control.

Bank Up **9(N+1), 7E, 7F, 9(N+1), 7E, 00**

Bank Down **9(N+1), 7F, 7F, 9(N+1), 7F, 00**

MMC (Transport Control)

Sysex message **F0, 7F, 7F, 06, TC, F7**

Where **TC** transport control:

01 = Stop

02 = Play

04 = Fast Forward

05 = Rewind

06 = Record Strobe

09 = Pause

Mute control

Mute on NOTE ON with velocity > or = 40 followed by NOTE OFF
9N, CH, 7F, 8N, CH, 00

Mute off NOTE ON with velocity < 40 followed by NOTE OFF
9N, CH, 3F, 8N, CH, 00

Received Mute messages

Velocity 00 and NOTE OFF messages are ignored
Velocity 01 to 3F = Mute off
Velocity 40 to 7F = Mute on

NRPN Parameter control

Qu mixer parameters are transmitted and received as MIDI NRPN (Non-Registered Parameter Number) messages. The MSB (most significant byte) selects the mixer channel (CH), and the LSB (least significant byte) selects the parameter number (ID). The data entry MSB sets the parameter value (VA) and LSB sets the index value for its range (VX) where needed.

(NRPN MSB)	(NRPN LSB)	(Data MSB)	(Data LSB)
BN, 63, CH,	BN, 62, ID,	BN, 06, VA	BN, 26, VX

Group Mode BN, 63, CH, BN, 62, 5E, BN, 06, VA BN, 26, 00
Where VA Group mode = 00, Mix mode = 01

Note This is unidirectional – Sent from mixer but not received

Fader BN, 63, CH, BN, 62, 17, BN, 06, VA BN, 26, 07
Where VA -inf to +10dB = 00 to 7F, 0dB = 6B (see table)

Pan BN, 63, CH, BN, 62, 16, BN, 06, VA BN, 26, VX
Where VA Full Left = 00 to Centre = 25 to Full Right = 4A
VX 04, 05, 06, 07 = Mix 5-6, 7-8, 9-10, LR
VX 08, 09, 0A, 0B = Grp 1-2, 3-4, 5-6, 7-8 (in Mix mode)
VX 0C, 0D = MTX1-2, 3-4 (not Qu-16)

LR Assign BN, 63, CH, BN, 62, 18, BN, 06, VA BN, 26, 07
Where VA Off = 00, On = 01

Mix Assign BN, 63, CH, BN, 62, 55, BN, 06, VA BN, 26, VX
Where VA Off = 00, On = 01
VX 00 to 0B = Mix1 to 9-10, LR
VX 10 to 13 = FX send 1-4 (Qu-16 FX1,2 only)
VX 08, 09, 0A, 0B, 0C, 0D = Grp1-2 to 7-8, MTX1-2 to 3-4

Mute Grp Assign BN, 63, CH, BN, 62, 5C, BN, 06, VA BN, 26, 07
Where VA Off Mute Grp 1-4 = 00 to 03,
On Mute Grp 1-4 = 40 to 43

DCA Grp Assign	BN, 63, CH, BN, 62, 40, BN, 06, VA BN, 26, 07
Where	VA Off Mute Grp 1-4 = 00 to 03 , On Mute Grp 1-4 = 40 to 43
Mix Pre/Post	BN, 63, CH, BN, 62, 50, BN, 06, VA BN, 26, VX
Where	VA Post = 00 , Pre = 01 VX 00 to 06 = Mix1 to 9-10 VX 08 to 0B = Grp1-2 to 7-8 (in Mix mode) VX 10 to 13 = FX send 1-4 (Qu-16 FX1,2 only) VX 0C, 0D = MTX1-2, 3-4 (not Qu-16)
Send Level	BN, 63, CH, BN, 62, 20, BN, 06, VA BN, 26, VX
Where	VA -inf to +10dB = 00 to 7F (see table) VX 00 to 06 = Mix1 to 9-10 VX 08 to 0B = Grp1-2 to 7-8 (in Mix mode) VX 10 to 13 = FX send 1-4 (Qu-16 FX1,2 only) VX 0C, 0D = MTX1-2, 3-4 (not Qu-16)
PAFL select	BN, 63, CH, BN, 62, 51, BN, 06, VA BN, 26, 07
Where	VA Off = 00 , On = 01
Ch USB Source	Switches between channel current Preamp and current USB source BN, 63, CH, BN, 62, 12, BN, 06, VA BN, 26, 00 Where VA Off (Preamp) = 00 , On (USB) = 01
Ch Preamp Source	Switches between mixer rear panel and remote AR rack input source BN, 63, CH, BN, 62, 57, BN, 06, VA BN, 26, 00 Where VA Off (Local) = 00 , On (dSNAKE) = 01
dSNAKE Patch	BN, 63, CH, BN, 62, 5D, BN, 06, VA BN, 26, 00 Where VA = dSNAKE input socket index 00 to 27 Note This is unidirectional – Sent from mixer but not received
Local Preamp	Applies to rear panel local inputs only BN, 63, CH, BN, 62, ID, BN, 06, VA BN, 26, 07 Where
Gain	ID = 19 VA Gain -5dB to +60dB = 00 to 7F (see table)
48V PP	ID = 69 VA Off = 00 , On = 01
dSNAKE Preamp	Applies to remote AR rack inputs only BN, 63, CH, BN, 62, ID, BN, 06, VA BN, 26, VX Where
Gain	ID = 58 VA Gain +5dB to +60dB = 00 to 7F (see table)
Pad	ID = 59 VA Out = 00 , In = 01
48V PP	ID = 5A VA Off = 00 , On = 01 VX = dSNAKE socket index (00 to 27) (dSNAKE input patch)

Digital Trim		Applies to USB source to channel only BN, 63, CH, BN, 62, 52, BN, 06, VA BN, 26, 07 Where VA Trim -24 to +24dB = 00 to 7F 0dB = 40
Stereo Trim		Applies to local ST1, ST2 and ST3 inputs only BN, 63, CH, BN, 62, 54, BN, 06, VA BN, 26, 07 Where VA Trim -24 to +24dB = 00 to 7F 0dB = 40
Polarity		BN, 63, CH, BN, 62, 6A, BN, 06, VA BN, 26, 07 Where VA Off (normal) = 00 , On (reversed) = 01
Insert In/Out		BN, 63, CH, BN, 62, 6B, BN, 06, VA BN, 26, 07 Where VA Out = 00 , In = 01
PEQ		BN, 63, CH, BN, 62, ID, BN, 06, VA BN, 26, 07 Where
	LF Gain	ID = 01 VA -12 to +12dB = 00 to 7F 0dB = 40
	LF Freq	ID = 02 VA 20Hz to 20 kHz = 00 to 7F
	LF Width	ID = 03 VA 1.5 to 1/9 Oct = 00 to 7F
	LF Type	ID = 04 VA Bell = 00 , Shelf = 06
	LM Gain	ID = 05 VA -12 to +12dB = 00 to 7F 0dB = 40
	LM Freq	ID = 06 VA 20Hz to 20 kHz = 00 to 7F
	LM Width	ID = 07 VA 1.5 to 1/9 Oct = 00 to 7F
	HM Gain	ID = 09 VA -12 to +12dB = 00 to 7F 0dB = 40
	HM Freq	ID = 0A VA 20Hz to 20 kHz = 00 to 7F
	HM Width	ID = 0B VA 1.5 to 1/9 Oct = 00 to 7F
	HF Gain	ID = 0D VA -12 to +12dB = 00 to 7F 0dB = 40
	HF Freq	ID = 0E VA 20Hz to 20 kHz = 00 to 7F
	HF Width	ID = 0F VA 1.5 to 1/9 Oct = 00 to 7F
	HF Type	ID = 10 VA Bell = 00 , Shelf = 06
PEQ	In/Out	BN, 63, CH, BN, 62, 11, BN, 06, VA BN, 26, 00 Where VA Out = 00 , In = 01
HPF	Freq	BN, 63, CH, BN, 62, 13, BN, 06, VA BN, 26, 07 Where VA 20Hz to 20kHz = 00 to 7F
HPF	In/Out	BN, 63, CH, BN, 62, 14, BN, 06, VA BN, 26, 00 Where VA Out = 00 , In = 01
GEQ	Gain	BN, 63, CH, BN, 62, 70, BN, 06, VA BN, 26, VX Where VA Gain -12 to +12dB = 00 to 7F VX 00 to 1B = Each of 28 bands (see table)
GEQ	In/Out	BN, 63, CH, BN, 62, 71, BN, 06, VA BN, 26, 00 Where VA Out = 00 , In = 01

Gate		BN, 63, CH,	BN, 62, ID,	BN, 06, VA	BN, 26, 07
	Where				
	Attack	ID = 41	VA	50us to 300ms = 00 to 7F	
	Release	ID = 42	VA	10ms to 1s = 00 to 7F	
	Hold	ID = 43	VA	10ms to 5s = 00 to 7F	
	Threshold	ID = 44	VA	-72 to +18dB = 00 to 7F	
	Depth	ID = 45	VA	0 to 60dB = 00 to 7F	
Gate	In/Out	BN, 63, CH,	BN, 62, 46,	BN, 06, VA	BN, 26, 00
	Where	VA	Out = 00 , In = 01		
Comp		BN, 63, CH,	BN, 62, ID,	BN, 06, VA	BN, 26, 07
	Where				
	Type	ID = 61	VA	4 types = 00 , 01 , 02 , 03	
	Attack	ID = 62	VA	300us to 300ms = 00 to 7F	
	Release	ID = 63	VA	100ms to 2s = 00 to 7F	
	Knee	ID = 64	VA	Hard knee = 00 , Soft knee = 01	
	Ratio	ID = 65	VA	1:1 to inf = 00 to 7F , 2.6:1 = 50	
	Threshold	ID = 66	VA	-46 to +18dB = 00 to 7F	
	Gain	ID = 67	VA	0 +18dB = 00 to 7F	
Comp	In/Out	BN, 63, CH,	BN, 62, 68,	BN, 06, VA	BN, 26, 00
	Where	VA	Out = 00 , In = 01		
Delay	Time	BN, 63, CH,	BN, 62, 6C,	BN, 06, VA	BN, 26, 07
	Where	VA	Input 0 to 85ms = 00 to 40	(linear)	
		VA	Mix 0 to 170ms = 00 to 7F	(linear)	
		VA	Group 0 to 170ms = 00 to 7F	(linear)	
		VA	Matrix 0 to 170ms = 00 to 7F	(linear)	
Delay	In/Out	BN, 63, CH,	BN, 62, 6D,	BN, 06, VA	BN, 26, 00
	Where	VA	Out = 00 , In = 01		

Remote Shutdown

Remote Shutdown **BN, 63, 00** **BN, 62, 5F** **BN, 06, 00** **BN, 26, 00**

Note: The QU mixer will require a hard power reset to switch on the mixer.

FX Parameter Control

Delay FX Time

To set delay time. Can be used for Tap Tempo.
 Can use one or two NRPN messages:
 Use MSB message only for course time value resolution.
 Use LSB followed by MSB message for fine resolution.

LSB: **BN, 63, CH,** **BN, 62, 49,** **BN, 06, VAf** **BN, 26, VX**

MSB: **BN, 63, CH,** **BN, 62, 48,** **BN, 06, VAc** **BN, 26, VX**

Where **VAf** Fine resolution time value = **00** to **7F**
VAc Course resolution time value = **00** to **7F**
VX Delay parameter **05** = Left tap
 07 = Right tap
 (See table for examples of time value)

Delay FX Link

To link or unlink the Left and Right tap time.

BN, 63, CH, **BN, 62, 48,** **BN, 06, VA** **BN, 26, 06**

Where **VA** Off (unlinked) = **00**
 On (linked) = **7F**

Scene Recall

Qu uses **Bank Select** and **Program Change** messages for Scene recall. Only Bank 1 is used.

Transmitted Scene message

Qu transmits this message when a Scene is recalled using the touch screen or a SoftKey:

(Bank1 MSB) (Bank1 LSB) Recall Scene
BN, 00, 00, **BN, 20, 00,** **CN, SS**

Where **SS** = Scene1 to 100 = **00** to **63** (see table)

Received Scene message

Qu responds to the following message if Bank1 is currently selected:

Recall Scene
CN, SS

Where **SS** = Scene1 to 100 = **00** to **63** (see table)

To set Bank1

Qu will ignore Scene change messages if the Bank is not set to 1.

(Bank1 MSB) (Bank1 LSB)
BN, 00, 00, **BN, 20, 00**

Device Connection

Note Qu currently allows only one TCP MIDI connection at a time over its Network port.

TCP Client Configuration

Clients should be configured to use TCP port 51325

Active Sensing

Qu supports MIDI Active Sensing over its TCP/IP Ethernet connection to detect connection status. Qu will send an initial Active Sense byte (FE) once an Ethernet connection is established, and then once every 300ms or so during any period of inactivity.

Qu also responds to Active Sense. If it receives an Active Sense byte it will expect to receive regular MIDI data from that point onwards (either valid control data, or more Active Sense bytes during any period of inactivity). If it does not receive any data for 12 seconds, it will close the Ethernet connection.

Qu uses Sysex messages to communicate much of its data.

Sysex Header

Sysex Header

	A&H ID	Qu mixer	Major/Minor version	MIDI channel
F0,	00, 00, 1A,	50, 11,	01, 00,	0N

Get System State

An external controller such as an iPad running the Qu-Pad app can use MIDI Sysex messages to request and receive the current parameter state of the Qu mixer.

Note On request, the mixer MIDI channel (N) is not known therefore an 'All Call' Sysex Header is sent. The reply returns the MIDI channel number. This number should be used in subsequent messages.

REQUEST: Sysex Header (All Call), 10 <iPadFlag>, F7

Where Sysex Header (All Call) = F0, 00, 00, 1A, 50, 11, 01, 00, 7F

And <iPadFlag> = 1 identifies the incoming connection as Qu-pad.

REPLY: Sysex Header, 11, <BoxID>, <Version>, F7

Where <BoxID> identifies the outgoing connection Qu mixer model

Where: 1 = Qu-16

2 = Qu-24

3 = Qu-32

4 = Qu-Pac

<Version> = <Major>,<Minor> = Qu firmware version (7bit data)

Subsequent push of NRPN messages to update current state.

Subsequent End Sync Response:

Sysex Header, 14, F7

If <iPadFlag> is set in the initial request the Qu mixer will expect to receive an Active Sense byte within 5 seconds. If not, it will close the Ethernet connection. This is how the lost communication mechanism is enforced for Qu-Pad.

Channel Naming

Get Name from Qu

REQUEST: Sysex Header, 01, CH, F7

REPLY: Sysex Header, 02, CH, <Name>, F7

Where <Name> = string of hex ascii characters

Set Name Sysex Header, 03, CH, <Name>, F7

Where <Name> = string of hex ascii characters

Get Meter Data

An external controller such as an iPad running the Qu-Pad app can use MIDI Sysex messages to request and receive the current meter data from the Qu mixer.

REQUEST:

Sysex Header, 12, < MeterOnOff > , F7

REPLY:

Sysex Header, 13, < MeterData > , F7

Where < MeterData > = Push of all meter data (Described below).

Where < MeterOnOff > = 0 (meters Off), 1 (meters On)

Meter values are signed dB values, coded as fixed point 7Q8 offset 8000 format, stored as unsigned 16 bit numbers, (transmitted in "7-bit-ized" format in the Sysex).

Encoding of meter data:

The 8-bit file data needs to be converted to 7-bit form, with the result that every 7 bytes of file data translates to 8 bytes in the MIDI stream.

For each group of 7 bytes of file data, the top bit from each is used to construct an eighth byte, which is sent first. For example:

AAAAaaaa BBBBbbbb CCCccccc DDDDdddd EEEeeeeee FFFFffff GGGGgggg

becomes :

0ABCDEFG 0AAAAaaaa 0BBBBbbbb 0CCCccccc 0DDDdddd 0EEEeeee 0FFFffff 0GGGgggg

The final group may have less than 7 bytes, and is coded as follows (example with 2 bytes in the final group):

0AB00000 0AAAAaaaa 0BBBBbbbb

Example:	7-bit-ized binary	00100000 01111100 00000000
	Unpacks to 8-bit-ized binary	01111100 10000000
	Equivalent to hexadecimal	7C80
	Remove the offset:	(int16_t) 7C80 – (int16_t) 8000 = FC80
	Float and scale:	(float) FC80 / 256.0f = -3.5dB

Transmission of meter data:

The meter data is transmitted in blocks of data in the following order:

Qu-16

16 Mono Input blocks
80 unused meters
3 Stereo Input blocks
20 unused meters
4 Mono Mix blocks
4 Stereo Mix blocks
1 Stereo Monitor block
4 Stereo FX blocks

Qu-24

24 Mono Input blocks
3 Stereo Input blocks
180 unused meters
4 Mono Mix blocks
4 Stereo Mix blocks
2 Stereo Group blocks
2 Stereo Matrix blocks
1 Stereo Monitor block
4 Stereo FX blocks

Qu-32, Qu-Pac

24 Mono Input blocks (CH1-24)
3 Stereo Input blocks
20 unused meters
8 Mono Input blocks (CH25-32)
4 Mono Mix blocks
4 Stereo Mix blocks
4 Stereo Group blocks
2 Stereo Matrix blocks
1 Stereo Monitor block
4 Stereo FX blocks

Note Stereo Mix blocks include Mix 5-6, 7-8, 9-10, LR

The meter blocks transmit the following meter data:

Mono Input block

Post Preamp
Post PEQ
Post Compressor
Post Delay
Gate Side Chain
Compressor Side Chain
Direct Out
Gate Gain reduction
Compressor Gain Reduction
Ducker Gain Reduction

Mono Mix block

TB/SigGen
Pre-Insert
Post-PEQ
Post-GEQ
Post Compressor
Post Fader
Post insert
Compressor Side Chain
Compressor Gain Reduction
Ducker Gain Reduction

Stereo Input block

Post Preamp L
Post PEQ L
Post Compressor L
Post Delay L
Gate Side Chain L
Compressor Side Chain L
Direct Out L
Gate Gain reduction L
Compressor Gain Reduction L
Ducker Gain Reduction L
Post Preamp R
Post PEQ R
Post Compressor R
Post Delay R
Gate Side Chain R
Compressor Side Chain R
Direct Out R
Gate Gain reduction R
Compressor Gain Reduction R
Ducker Gain Reduction R

Stereo Mix / Group / Matrix block

TB/SigGen L
Pre-Insert L
Post PEQ L
Post GEQ L
Post Compressor L
Post Fader L
Post Insert L
Compressor Side Chain L
Compressor Gain Reduction L
Ducker Gain Reduction L
TB/SigGen R
Pre-Insert R
Post PEQ R
Post GEQ R
Post Compressor R
Post Fader R
Post Insert R
Compressor Side Chain R
Compressor Gain Reduction R
Ducker Gain Reduction R

Stereo Monitor block

PAFL L
PAFL R
PAFL Mono sum
Talkback
Signal Generator
Main Pre Fader L
Main Pre Fader R
Main Post Fader L
Main Post Fader R
Main Mono Sum Pre Fader
Main Mono Sum Post Fader
USB A Record Out L
USB A Record Out R
3 Unused Meters

RTA 31 bands L

RTA 31 bands R

Stereo FX block

Send L (at FX device input)
Send R (")
Send Mono sum
Pre PEQ L
Pre PEQ R
Tap Tempo L
Tap Tempo R
Post PEQ L
Post PEQ R
9 unused meters

MIDI channel			Scene number				Input Channel		Local Gain value		GEQ Bands	
N		N+1	SS		SS	CH		19	VA	70 VX		
Qu	Hex	DAW	Scene	Hex	Scene	CH	Hex	dB	Hex	Freq	Hex	
1	0	2	1	00	65	40	1	20	+60	7F	31.5Hz	00
2	1	3	2	01	66	41	2	21	+50	6B	40Hz	01
3	2	4	3	02	67	42	3	22	+40	57	50Hz	02
4	3	5	4	03	68	43	4	23	+30	44	63Hz	03
5	4	6	5	04	69	44	5	24	+20	30	80Hz	04
6	5	7	6	05	70	45	6	25	+10	1D	100Hz	05
7	6	8	7	06	71	46	7	26	+5	13	125Hz	06
8	7	9	8	07	72	47	8	27	0	0A	160Hz	07
9	8	10	9	08	73	48	9	28	-5	00	200Hz	08
10	9	11	0A	09	74	49	10	29			250Hz	09
11	A	12	0B	0A	75	4A	11	2A			315Hz	0A
12	B	13	0C	0B	76	4B	12	2B			400Hz	0B
13	C	14	0D	0C	77	4C	13	2C			500Hz	0C
14	D	15	0E	0D	78	4D	14	2D			630Hz	0D
15	E	16	0F	0E	79	4E	15	2E			800Hz	0E
16	F	1	00	0F	80	4F	16	2F			1kHz	0F
					81	50	17	30			1k25	10
					82	51	18	31			1k6	11
					83	52	19	32			2kHz	12
					84	53	20	33			2k5	13
					85	54	21	34			3k15	14
					86	55	22	35			4kHz	15
					87	56	23	36			5kHz	16
					88	57	24	37			6k3	17
					89	58	25	38			8kHz	18
					90	59	26	39			10kHz	19
					91	5A	27	3A			12k5	1A
					92	5B	28	3B			16kHz	1B
					93	5C	29	3C				
					94	5D	30	3D				
					95	5E	31	3E				
					96	5F	32	3F				
					97	60	ST1	40				
					98	61	ST2	41				
					99	62	ST3	42				
					100	63						

MIDI Strip		Mute Sel PAFL			
MS		KY			
Strip	Hex	Strip	Hex	Hex	Hex
1	00	1	00	20	40
2	01	2	01	21	41
3	02	3	02	22	42
4	03	4	03	23	43
5	04	5	04	24	44
6	05	6	05	25	45
7	06	7	06	26	46
8	07	8	07	27	47
9	08	9	08	28	48
10	09	10	09	29	49
11	0A	11	0A	2A	4A
12	0B	12	0B	2B	4B
13	0C	13	0C	2C	4C
14	0D	14	0D	2D	4D
15	0E	15	0E	2E	4E
16	0F	16	0F	2F	4F
17	10	17	10	30	50
18	11	18	11	31	51
19	12	19	12	32	52
20	13	20	13	33	53
21	14	21	14	34	54
22	15	22	15	35	55
23	16	23	16	36	56
24	17	24	17	37	57
25	18	25	18	38	58
26	19	26	19	39	59
27	1A	27	1A	3A	5A
28	1B	28	1B	3B	5B
29	1C	29	1C	3C	5C
30	1D	30	1D	3D	5D
31	1E	31	1E	3E	5E
32	1F	32	1F	3F	5F

FX Ret		CH	
CH	Hex	CH	Hex
1	08		
2	09		
3	0A		
4	0B		

FX Send			CH	VX
CH	Hex	Hex	CH	VX
1	00	10		
2	01	11		
3	02	12		
4	03	13		

Mix			CH	VX
Mix	Hex	Hex	CH	VX
1	60	00		
2	61	01		
3	62	02		
4	63	03		
5-6	64	04		
7-8	65	05		
9-10	66	06		
LR	67	07		
Grp1-2	68	08		
Grp3-4	69	09		
Grp5-6	6A	0A		
Grp7-8	6B	0B		
MTX1-2	6C	0C		
MTX3-4	6D	0D		

Local Gain value		dSNAKE Gain value		Fader/Send value	
dB	Hex	dB	Hex	dBu	Hex
+60	7F	+60	7F	+10	7F
+50	6B	+50	67	+5	74
+40	57	+40	50	0	6B
+30	44	+35	45	-5	61
+20	30	+30	39	-10	57
+10	1D	+25	2E	-15	4D
+5	13	+20	22	-20	43
0	0A	+10	0B	-25	39
-5	00	+5	00	-30	2F

Delay FX time		
Time	Hex	Hex
5ms	00	00
100ms	44	31
200ms	54	22
400ms	63	77
800ms	73	68
1.36sec	7F	7F

Compressor Type		
Type	Hex	Hex
Manual Peak	00	00
Manual RMS	01	01
Auto Slow Opto	02	02
Auto Punchbag	03	03

Mute Group			Mute Grp Assign		
MG	Hex	Hex	MG	off	on
1	50		1	00	40
2	51		2	01	41
3	52		3	02	42
4	53		4	03	43

DCA Group			DCA Grp Assign		
MG	Hex	Hex	MG	off	on
1	10		1	00	40
2	11		2	01	41
3	12		3	02	42
4	13		4	03	43